

BELKIN.

TuneCast® Auto LIVE for iPhone and iPod User Manual

8820-00589 F8Z498-P



TABLE OF CONTENTS

Table of Contents	SECTIONS	1	2	3	4	5	6	7	8
1 Introduction									1
2 Get the ClearScan LIVE App									2
3 Connect your TuneCast Auto									3
4 Find an Open FM Station									4
Use ClearScan to find the best station (recommended)									4
Find a station manually									5
Store and select stations									6
5 Use the PRO Button to Boost Sound									7
6 Get the Most Out of TuneCast Auto									8
Charge your iPhone or iPod									8
Optimize the sound quality of your TuneCast Auto									8
7 Safety Warnings									9
8 Information									10

INTRODUCTION

Table of Contents

SECTIONS

1

2

3

4

5

6

7

8

TuneCast Auto charges your iPod while you play your music over your car's FM radio. Now you can use your iPhone or iPod touch to control your TuneCast Auto. Just download the free ClearScan LIVE app from the App Store (see instructions on the next page).

GET THE CLEARSCAN LIVE APP


ClearScan LIVE lets you control your TuneCast Auto LIVE directly from your iPhone or iPod touch. ClearScan LIVE also provides improved ClearScan results by:

- Using your GPS location to find the best FM station in your area
- Recommending open stations based on what other people in your area are using


Look for ClearScan LIVE in the App Store on iTunes. See instructions in the app's Help section for more information.

CONNECT YOUR TUNECAST AUTO

1. Turn down your stereo's volume.
2. Connect your TuneCast Auto to the cigarette lighter or power outlet in your vehicle.



3. Connect your iPhone or iPod to your TuneCast Auto.



Note: In order to comply with government regulations, European versions of TuneCast Auto will automatically turn off if there is no audio for approximately 60 seconds. It will automatically turn on when it detects audio from your iPhone or iPod. You can also press the “m1” or “m2” button to turn on your TuneCast Auto.


FIND AN OPEN FM STATION

There are two ways to find an open FM station: by using ClearScan or selecting an FM station manually.

Use ClearScan to find the best station (recommended)

Your TuneCast Auto uses ClearScan technology to constantly scan for the clearest FM frequency in your area.

1. Press the  "ClearScan" button. Your TuneCast Auto will display the best frequency.




2. Tune your stereo to the frequency on your TuneCast Auto display.

FIND AN OPEN FM STATION

Find a station manually

If you want to transmit on a specific frequency, you can manually select it on your TuneCast Auto:

1. First, tune your car radio to an open station, one that plays only static or has a very weak radio signal.
2. Press the + or - button on your TuneCast Auto to select the same station.



To identify the best available frequencies in your area, visit www.belkin.com/mybestfm.

FIND AN OPEN FM STATION


Save and select stations

You can save two stations using the “m1” and “m2” buttons.

1. To save a station, select the desired frequency on your TuneCast Auto using the + or - buttons.
2. Press and hold the “m1” or “m2” button for two seconds. The “m1” or “m2” icon will flash on the screen when the station is saved.
3. To recall a saved station, press the “m1” or “m2” button. Your TuneCast Auto will change to the saved station.

USE THE PRO BUTTON TO BOOST SOUND

If you find the sound is too weak, press “PRO” to boost the sound coming from your iPod. PRO will cycle through the following settings:

PRO Setting	Use for...	Description
Normal	All types of audio	No change to audio
PRO 1	Most types of music	Increases the average volume of the audio
PRO 2	Quieter music	Increases the average volume more than PRO 1; may cause distortion of louder music
	Audio books, mono recordings, podcasts	Increases the average volume and transmits in mono
	Try this if you do not receive a clear signal	

GET THE MOST OUT OF TUNECAST AUTO

Charge your iPhone or iPod

Your TuneCast Auto will charge your iPhone or iPod while it is connected to a power outlet and receiving power. If your iPhone or iPod is not charging, make sure your TuneCast Auto is correctly connected to the power outlet and that your iPhone or iPod is securely connected to your TuneCast Auto. The indicator light on the cigarette lighter adapter should be lit.

Note: Some vehicles do not provide power to the power outlet unless the vehicle is in ignition mode or the engine is running.

Optimize the sound quality of your TuneCast Auto

A variety of car radio and antenna configurations are available and you may optimize the sound quality in your car based on the location of your TuneCast Auto (for example, placing the TuneCast Auto on the center console may yield better performance than other locations within your vehicle).

SAFETY WARNINGS

Do not attempt to connect your TuneCast Auto while driving. Make sure your TuneCast Auto fits securely and firmly into the power outlet before driving.

Do not attempt to adjust or retrieve an unsecured TuneCast Auto or iPhone or iPod while driving. Position the TuneCast Auto so that both the TuneCast Auto and the iPhone or iPod do not interfere with any of the operating controls of the car.

Do not insert any objects other than the cigarette lighter adapter into the power outlet without disconnecting the battery of the car first. Failure to observe this safety warning can result in injury or property damage.

Belkin does not assume any responsibility for personal injury or property damage incurred due to hazardous driving as a result of interaction with the TuneCast Auto, the iPhone or iPod, or the vehicle's power outlet.

INFORMATION

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Belkin International, Inc., is not responsible for any interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment.

Belkin International, Inc., Limited 1-Year Product Warranty

What this warranty covers.

Belkin International, Inc. (“Belkin”) warrants to the original purchaser of this Belkin product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Belkin warrants the Belkin product for one year.

What will we do to correct problems?

Product Warranty.

Belkin will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product). Belkin reserves the right to discontinue any of its products without notice, and disclaims any limited warranty to repair or replace any such discontinued products. In the event that Belkin is unable to repair or replace the product (for example, because it has been discontinued), Belkin will offer either a refund or a credit toward the purchase of another product from Belkin.com in an amount equal to the purchase price of the product as evidenced on the original purchase receipt as discounted by its natural use.

What is not covered by this warranty?

All above warranties are null and void if the Belkin product is not provided to Belkin for inspection upon Belkin's request at the sole expense of the purchaser, or if Belkin determines that the Belkin product has been improperly installed, altered in any way, or tampered with. The Belkin Product Warranty does not protect against acts of God such as flood, lightning, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

How to get service.

To get service for your Belkin product you must take the following steps:

1. Contact Belkin International, Inc., at 12045 E. Waterfront Drive, Playa Vista, CA 90094, Attn: Customer Service, or call (800)-223-5546, within 15 days of the Occurrence. Be prepared to provide the following information:
 - a. The part number of the Belkin product.
 - b. Where you purchased the product.
 - c. When you purchased the product.
 - d. Copy of original receipt.
2. Your Belkin Customer Service Representative will then instruct you on how to forward your receipt and Belkin product and how to proceed with your claim.

Belkin reserves the right to review the damaged Belkin product. All costs of shipping the Belkin product to Belkin for inspection shall be borne solely by the purchaser. If Belkin determines, in its sole discretion, that it is impractical to ship the damaged equipment to Belkin, Belkin may designate, in its sole discretion, an equipment repair facility to inspect and estimate the cost to repair such equipment. The cost, if any, of shipping the equipment to and from such repair facility and of such estimate shall be borne solely by the purchaser. Damaged equipment must remain available for inspection until the claim is finalized. Whenever claims are settled, Belkin reserves the right to be subrogated under any existing insurance policies the purchaser may have.

How state law relates to the warranty.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF BELKIN. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR, EXCEPT AS REQUIRED BY LAW, IMPLIED, INCLUDING THE IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL BELKIN BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL OR MULTIPLE DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY BELKIN PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental, consequential, or other damages, so the above limitations may not apply to you.

BELKIN®

www.belkin.com

US

<http://www.belkin.com/support>

UK

<http://www.belkin.com/uk/support>

Australia

<http://www.belkin.com/au/support>

New Zealand

<http://www.belkin.com/au/support>

Singapore

1800 622 1130

Europe

<http://www.belkin.com/uk/support>

© 2010 Belkin International, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed. iPod, iTunes, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.

