BELKIN

®

belkin.com

Internet Connection Sharing
Quick Setup Guide

For HP IPAQ Pocket PC Models: H1940, H1945, H2210, H2215, H5450, H5455, H5550, H5555 also works with other Pocket PCs using Widcomm BTCE ver.1.3.x

Use with Belkin Bluetooth PC Adapters: F8T001, F8T002 and F8T003

BELKIN

®

Note: Please be sure to enable Internet Connection Sharing on your Windows PC before you begin this guide. Please refer to your Windows Help for more information on Internet Connection Sharing.

SECTION 1: Pairing your Pocket PC to your Computer

Step 1: Tap on the **Bluetooth icon** located in the lower right corner of the Today Screen. Select Bluetooth Manager.
*Note: Be sure that your Bluetooth Radio is turned **ON**.*

Step 2: Tap on the **Tools** located in the menu bar located at the bottom of your screen. Then select **Paired Devices.**

BELKIN

Step 3: Tap on the **Add** button.

> **Bluetooth Manage** ⟲ 📶 11:40 **ok**
>
> **Bluetooth: Paired devices**
> _____
>
> [**Add**]   [Remove]
> _____
>
>   ⌨|▲

Step 4: Tap on **Search icon** located to the right of the **Device** text box.
This will begin a search for all Bluetooth devices in your area.

> **Bluetooth Manage** ⟲ 📶 11:40 **ok**
>
> **Bluetooth: Device Pairing**
> _____
>
> Device: [   ] 🔍
>
> Passkey: [   ]
>
>   [**Cancel**]
>
> — **How to use this screen** —
>
> To add a device to the list of paired
> devices, tap the lookup icon, select a
> device, enter the passkey and then tap
> OK.
>
> The Bluetooth pairing procedure
> establishes a secret key that is used in
> all future connections to authenticate
> device identity and encrypt data.
> _____
>
>   ⌨|▲

BELKIN

Step 5: Tap on the devices you would like to establish a connection for your Pocket PC.


Step 6: Enter a **Passkey** in the Passkey Text Box and tap "OK". For example "0000" or "1234." The passkey could be any alphanumeric number you want.


BELKIN

Step 7: Check your Computer. You will be prompted to enter the same Passkey on the Bluetooth computer you are trying to Synchronize to.


**Step 8:** Enter the Passkey and click **OK**. Your devices are now paired.

SECTION 2: Configuring your Network Connection

Step 1: Go to My Bluetooth Places and Click on "**View My Bluetooth Places** (Windows XP)" or double click on "**My Device**"(for Windows 98, ME or 2K).


Step 2: Right click on **My Bluetooth Network Access** and select **Properties**.

BELKIN

**Step 3:** Make sure there is a check mark next to **Startup Automatically**.

From the drop-down menu select the following service, **"Allow other devices to access the Internet/LAN via this computer."** Then click the **Apply** button to save the changes.

SECTION 2: Connecting via Network Access

Step 1: Tap on the **Bluetooth icon** located in the lower right corner of the Today Screen. Select Bluetooth Manager.
*Note: Be sure that your Bluetooth Radio is turned **ON**.*

Step 2: Tap on the **Bluetooth icon** located in the menu bar located at the bottom of your screen.

Step 3: Scroll down and select **Connect to the Internet.**

**Step 4:** Select "Connect via LAN…." And tap on the **Next**.

BELKIN

Step 5: Tap inside the center box to choose a device.

Step 6: Select the computer you previously paired in Section 1, Step 5.

Step 7: Your device will begin to search for the services offered by your computer.

Step 8: Tap on **Finish**.

BELKIN

Step 9: Your Pocket PC will attempt to establish a connection to your PC.

Step 10: Check your PC for a Bluetooth Authorization Request.


Step 11: Click OK to allow the Connection.

Step 12: Go to your Pocket PC device and tap on **OK**.

Step 13: Notice the connection window on you Pocket t PC device.
You should now be connected and online. Check your Internet Browser to confirm.

BELKIN

\To re-connect and Disconnect perform the following steps.

Step 1: Open the Bluetooth Manager and select the Internet icon for the PC you wish to establish an Internet connection through.

Connect

Disconnect

BELKIN